Flush plate Visign for Style 13

Product information Handling

Product information

Flush plate Visign for Style 13

for concealed cistern 2H, concealed cistern 2L, concealed cistern 2C, concealed cistern Standard 2S

Baujahr (ab): 01.05.2010

PDF **Flush plate Visign for Style 13**
Modellnr.: 8333.1 | Dateigröße: 3,5...

About these instructions for use

Intended use

Areas of use

Suitable cisterns

The flush plate is intended for the actuation of flushes on Viega concealed cisterns.

Installation is only possible in the following Viega concealed cisterns:

- Cistern model 2H
- Cistern model 2L

Ascertain which model is installed before mounting. The following information will help you to determine the model of the cistern installed:

Cistern 2H

The revision shaft of this cistern is found at a height of approx. 1 metre on the front.

Cistern 2L

The revision shaft of this cistern is either found at a height of approx. 75 cm on the front or on the top.

Product description

Overview

Component overview

1 - actuating rod
2 - basic panel
3 - flush plate
4 - threaded bolt

Technical data

The product exhibits the following technical data:

Flush volume

The flush volume for the flushes are:

- Small flush volume: approx. 3–4 litres
- Large flush volume: approx. 6–9 litres

For the setting of the flush see Setting the flush.

Handling

Assembly information

Required material and tools

Tool

The following tools are required for mounting:

- flat screwdriver
- knife (cutter)

Assembly

Prepare cistern

INFO!
The following work stages and diagrams differ depending on the cistern being used. The relevant steps are marked accordingly.

Requirements:

- The cistern is fitted into the front wall.
- The front wall is tiled.

1. Cut into shaft cover.

2. Remove shaft cover.

3. Score the revision shaft along the edge of the tiles with a knife.

   Angle the knife to do this so that the cut is made flush to the surface of the wall.

4. Cut the corners of the revision shaft vertically through to the wall surface.

- Bend out and pull down the sides of the revision shaft.

  The edge of the revisions shaft must be flush with the wall surface.

- Remove cistern cover.
- Remove and keep the threaded bolts from the cistern cover.
- Keep cistern casing.

- **INFO!**
  Only for assembly of the flush plate in cistern 2H or on the front of cistern 2L.
  Press the bow backwards from the mounting of the mechanism.

- **INFO!**
  Only for assembly of the flush plate on the top of cistern 2L.
  Press the bow backwards from the mounting of the mechanism.

- Turn the mechanism's lock by 90° in an anti-clockwise direction.
  - The mechanism is unlocked and can be removed.

- Remove and keep mechanism.

Flush pipelines (cistern 2H)

Requirements:

- The revision shaft is shortened in such a way that it is flush with the surface.
- Mechanism has been removed.

- Close corner valve.

Loosen flexible hose on the filling valve (SW 19).

Open the corner valve for a few seconds to rinse the pipe.

Re-close corner valve.

Connect the flexible hose onto the filling valve (SW 19).

Open corner valve.

Flush pipelines (cistern 2L)

Requirements:

- The revision shaft is shortened in such a way that it is flush with the upper edge of the tiles.
- Mechanism has been removed.

Close corner valve.

Loosen flexible hose on the filling valve (SW 19).

Open the corner valve for a few seconds to rinse the pipe.

Re-close corner valve.

Connect the flexible hose onto the filling valve.

Open corner valve.

Mount flush actuation

Mount mechanism (cistern 2H)

Hang the mechanism in the bow of the drain valve.

Insert mechanism.

The mechanism must sit exactly in the recesses in the cistern.

Turn the mechanism's lock by 90° in a clockwise direction.

→ The mechanism is locked.

Mount mechanism (cistern 2L)

INFO!
How to install the mechanism depends on whether the flush plate is to be fitted to the front or top of the cistern.

- Vertical installation (flush plate on the front of the cistern)
- Horizontal installation (flush plate on the top of the cistern)

Vertical installation (flush plate on the front of the cistern)

Hang the mechanism in the bow of the drain valve.

Insert mechanism.

The mechanism must sit exactly in the recesses in the cistern.

Turn the mechanism's lock by 90° in a clockwise direction.

➡ The mechanism is locked.

Horizontal installation (flush plate on the top of the cistern)

Hang the mechanism in the bow of the drain valve.

Insert mechanism.

In doing so, ensure that the tracks on the top and bottom edge of the mechanism are in the indentations in the revision shaft of the cistern.

Turn the mechanism's lock by 90° in a clockwise direction.

➡ The mechanism is locked.

Mounting the flush plate

Requirements:

- The flush actuation has been mounted.

Re-mount cistern casing.

Insert the threaded bolts so deeply that the upper edge of the threaded bolt sticks out approx. 15 mm behind the upper edge of the tiles.

Secure threaded bolts with a 90° turn.

Screw the upper actuating rod into the threaded holes of the mechanism.

Set the actuating rod flush with the surface of the tiles using the template supplied. If necessary, shorten the actuating rod on the thread with a cutting knife.

Screw the lower actuating rod into the threaded holes of the mechanism.

Set the actuating rod flush with the surface of the tiles using the template supplied. If necessary, shorten the actuating rod on the thread with a cutting knife.

Mount and screw on basic panel.

INFO!
The figure shows model 8334.1 as an example.

Place and press the flush plate onto the basic panel.

INFO!
The figure shows model 8334.1 as an example.

Commissioning

Setting the flush

Set the flush volume on the drain valve of the cistern.

Small flush volume (above): approx. 3–4 litres

Large flush volume (below): approx. 6–9 litres

Error, faults and remedy

Error	Cause	Remedy
WC does not flush	Cistern is not yet completely full	Wait until the cistern is sufficiently full
	No water in cistern, corner valve is closed	Open corner valve
WC flush runs through	Dirty seal in filling valve	Check seal, replace if necessary
	Dirty seal in drain valve	Check seal, replace if necessary
WC flush actuation does not work	The mechanism is not connected to the bow	Hang the mechanism in the bow

Care and maintenance

Maintenance tips

Normal soap or a mild cleaning agent can be used for regular care and prevention of lime scale on the flush plate. Under no circumstances should scouring agent or scratching objects be used.

Strong stains can be removed using typical household cleaner. Rinse the detergent thoroughly with clear water after the prescribed exposure time. There should be no residue on the components.

Disposal

Separate the product and packaging materials (e. g. paper, metal, plastic or non-ferrous metals) and dispose of in accordance with valid national legal requirements.