

2	CARASSA ALLUMINIO WIFOOD	GM2486430
4	MOTOR SOFTCOOKER Y09	GM5036100
5	SPINA ELASTICA DIN 1481 1,5X8	IX21481001.5008
6	HEATING ELEMENT 2000W_SOFTCOOKER 09	GM5256600
8	PCB SOFTCOOKER WIFOOD	GM5946340
9	FALSO FONDO WIFOOD	GM2483375
10	DISPLAY WIFOOD	GM2492100
12	SAFETY PROBE 10K FOR SOFTCOOKER 09	GM5826150
13	HEX.NUT DIN 934 M 6	IX2934006
14	THERMOSTAT PROBE FOR SOFTCOOKER 09	GM5826100
15	PAN HEAD SCREW DIN 7985 M5X10	IX27985005010
16	CESTELLO ALLUMINIO WIFOOD	GM3047300
17	WASHER DIN 125 D 5	IX2125005
18	MOTOR FAN _ SOFTCOOKER Y09	GM5036850
20	SPOKED IMPELLER SOFTCOOKER 09	GM5036870
21	HEX.SCREW DIN 933 M 3X06	IX2933003006
22	PROFILO TAGLIO TERMICO WIFOOD	GM4253670
23	RONDELLA DENTEL. DIN 6798-A D 3E	IX26798A003
25	BUSH _ SOFTCOOKER Y09	GM2486170
27	VITE SENZA TESTA DIN914 M3X4 P.CN	IX2914003004
33	VITE TCEI DIN 912 M 3X40	IX2912003040
34	FUSE HOLDER 15A 250V_SOFTCOOKER 09	GM5846050
36	FUSE 6,3X32 16A _ SOFTCOOKER Y09	GM5846055
38	ON/OFF SWITCH COMELUX 401/L	19410102
40	LOWER FAN, SOFT COOKER	GM5036875
42	WATER LEVEL SENSOR	GM2210200
44	DISTANZIALE ACCIAIO LIVELLOSTATO	GM4296275
46	BUSSOLA TIRANTE FISSAGGIO WIFOOD	GM2023195
50	TIE ROD KNOB M8	19562504
52	BUFFER D8,5XHT3,2 _ MIRRA 300	19563232
53	PIASTRA SUPPORTO MOTORE WIFOOD	GM5826050
54	TIE ROD WIFOOD	GM2023190
56	BRASS SPACER MM 8X16 _ SOFTCOOKER	GM4296235
57+58 GR	PAIR OF GREY ABS SIDES WI-FOOD	GM2492280
57+58 NR	PAIR OF BLACK ABS SIDES WI-FOOD	GM2492260
59	VITE AUTOF.TSP+ DIN 7982 D 3,9X19	IX279823.9019
60	CAVO 3X1,5 SCHUKO 3MT+GOMMINO	GM5506360
61	PRESSACAVO 1546.11.10 PG11 NERI	GM5893090