



ПЕЧЬ СВЧ HURAKAN HKN-WP900M

Поз	Наименование детали		
P01	door (with inlaid)	C01	H.V.fuse
P02	door window	C02	h.v. diode
P03	fuse socket	C03	h.v. capacitor
P04	capacitor holder	C04	wave filter
P05	fan shroud	C05	fan motor
P06	fan blade	C06	lamp
P07	door frame	C07	thermostat
P08	choke cover	C08	magnetron
P09	washer	C09	microswitch
P10	shaft	C10	microswitch
P11	roller ring	C11	microswitch
P12	glass tray	C12	transformer
P13	splash shield	C13	wiring harness
P14	upper hinge	C14	power cord
P16	cavity	C15	turntable motor
P17	label	C16	timer
P18	outer enclosure	B01	upper foam cushion
P21	lamp socket	B02	turntable cushion
P22	air duct bracket	B03	plastic bag
P23	microswitch mounting	B04	manual
P24	shockproof rubber	B05	protection film
P26	foot	B06	plastic bag
P27	base plate	B07	lower cushion
P28	lower hinge	B08	carton
P29	control panel	B09	cardboard
P34	handle		
P39	knob		
P44	panel cover board		
P107	left door flake		
P108	upper door flake		
P109	lower door flake		
P110	right panle flake		
P114	flake(in door frame)		
P117	door hook		
P118	door hook spring		
P119	upper panle flake		
P120	lower panle flake		