


cersanit



RU инструкция по монтажу и эксплуатации настенных смесителей

PL instrukcja montażu i obsługi baterii ściennych

EN installation and operation manual for wall-mounted faucets

KK қабырғалық араластырғыштарға арналған монтаждай және експлуатация бойынша нұсқаулық

AZ divardan asılan su kranlarının quraşdırılması və istismarı üzrə təlimat

UZ devorga ilindigan smesitellarni o'rnatish va foydalanish bo'yicha yo'riqnomasi

KG ъубалга асма чабыштыргычы орнотуу жана иштетуу боюнча нускама

KA კედლის შემრევის მონტაჟის და ექსპლუატაციის ინსტრუქცია

TK divar garyjylary gurnamak we ulanmak boyunça gözükdirme

HY Պատե ծորակների տեղադրման և օգտագործման հրահանգ

TJ дастурамал оид ба насбкунӣ ва истифодабарии омехтақунандаҳроӣ деворӣ

MN ханын ус холигч үгсрах ба ашиглах заавар




14mm/30mm/27mm




2.5mm




M24*1




1



2



3



4

