



FR4-44-8-88-8R-88R-10R-1010R

Pos. Ref.	Codice Code	Caratteristiche Features	Descrizione Description
1	CO6937	(FR4)	Carcassa <i>Housing</i>
1	CO6984	(FR44)	Carcassa <i>Housing</i>
1	CO6938	(FR8)	Carcassa <i>Housing</i>
1	CO6985	(FR88)	Carcassa <i>Housing</i>
1	CO6939	(FR8R)	Carcassa <i>Housing</i>
1	CO6986	(FR88R)	Carcassa <i>Housing</i>
1	CO6940	(FR10R)	Carcassa <i>Housing</i>
1	CO6987	(FR1010R)	Carcassa <i>Housing</i>
2	CO6941	(FR4)	Contenitore <i>Tank</i>
2	CO6942	(FR8)	Contenitore <i>Tank</i>
2	CO6943	(FR8R)	Contenitore <i>Tank</i>
2	CO6944	(FR10R)	Contenitore <i>Tank</i>
3	CO6945	(FR8R-10R)	Rubinetto <i>Cock</i>
4	CO6947	(FR8-8R)	Grata <i>Grate</i>
4	CO6948	(FR10R)	Grata <i>Grate</i>
5	CO6949	● (FR4) 2500W	Resistenza <i>Resistance</i>
5	CO6950	● (FR8-8R-FR10R-1010R) 3000W	Resistenza <i>Resistance</i>
6	CO6952		Molla <i>Spring</i>
7	CO6953		Molla <i>Spring</i>
8	CO6954	(FR4)	Cestello <i>Basket</i>
8	CO6955	(FR8-8R)	Cestello <i>Basket</i>
8	CO6956	(FR10R)	Cestello <i>Basket</i>
9	CO6957	(FR4)	Coperchio <i>Cover</i>
9	CO6958	(FR8-8R)	Coperchio <i>Cover</i>
9	CO6959	(FR10R)	Coperchio <i>Cover</i>
10	CO6960		Piedino <i>Foot</i>
11	CO6961		Fianco sx <i>Left side</i>
12	CO6962		Fianco dx <i>Right side</i>
13	CO6963	(FR4)	Pannello <i>Panel</i>
13	CO6964	(FR8-8R)	Pannello <i>Panel</i>
13	CO6965	(FR10R)	Pannello <i>Panel</i>
14	CO6966	(FR4)	Pannello <i>Panel</i>
14	CO6967	(FR8-8R)	Pannello <i>Panel</i>
14	CO6968	(FR10R)	Pannello <i>Panel</i>
15	CO7171	M16X15	Vite <i>Screw</i>
16	SL3550		Manopola <i>Knob</i>
17	CO6969	regolazione	Termostato <i>Thermostat</i>
18	CO6970	Verde	Spia <i>Indication</i>
19	CO6971	(FR8-8R)	Fondo <i>Bottom</i>
19	CO6988	(FR88-88R)	Fondo <i>Bottom</i>
19	CO6972	(FR10R)	Fondo <i>Bottom</i>
19	CO6989	(FR1010R)	Fondo <i>Bottom</i>
20	CO6973		Interruttore <i>Switch</i>
21	CO6974	Arancione	Spia <i>Indication</i>
22	CO6975		Guarnizione <i>Gasket</i>
23	CO6976		Teleruttore <i>Remote control switch</i>
24	CO6977		Microinterruttore <i>Microswitch</i>
25	CO6978	Sicurezza (FR4-44-8-8R-88-88R)	Termostato <i>Thermostat</i>
25	CO7379	Sicurezza (FR10-10R-1010R)	Termostato <i>Thermostat</i>
28	CO7442		Staffa <i>Stirrup</i>
29	CO7443	FR8	Fondo <i>Bottom</i>
29	CO7444	FR10	Fondo <i>Bottom</i>
29	CO7445	FR88	Fondo <i>Bottom</i>
29	CO7446	FR1010	Fondo <i>Bottom</i>
30	CO7172	(FR8-8R-88-88R)	Staffa <i>Stirrup</i>
30	CO7170	(FR10-10R-1010R)	Staffa <i>Stirrup</i>
33	CO7255	(FR4-44) Assembly	Resistenza <i>Resistance</i>
33	CO7256	(FR8-8R-88-88R) Assembly	Resistenza <i>Resistance</i>
33	CO7257	(FR10R-1010R) Assembly	Resistenza <i>Resistance</i>
34	CO8805	ferma capillare	Molla <i>Spring</i>

(*) : fuori produzione / out of production

● : ricambio consigliato / spare part suggested